



## EZ GasCal™ gas calibration station

The EZ GasCal™ is the perfect calibration station for the Vigilante AQS™ and Zephyr AQS™ gas sensor series. It enables calibration of underground gas sensors in a clean and controlled surface environment.

# Series = EZ GasCal™ - Gas calibration station

## 1+ = Options

(Extend matrix as required)



**EZGC** = EZ GasCal™ gas calibration station

EZ GasCal™ is the ideal calibration station for the Vigilante AQS™ and Zephyr AQS™ series of gas sensors. The station allows the calibration of the underground gas sensors in a clean and controlled surface environment.

The gas calibration station provides a dual plug-in receptacle to allow the calibration of digital smart sensors.

The calibration station comes complete with 2 metre power cord. The power supply required is 100-240 VAC, 47 to 63 Hz.

The EZ GasCal™ comes complete with an aluminum back panel for wall mounting.

CE Compliant

**B** = 2 metre cable with Type B plug for Canada, United States, and Mexico markets

**ESA** = ESA (Electrical Safety Authority) approval for general purpose applications.

**CSA** = CSA special approval for general purpose applications.

**SST** = Stainless Steel Tag; 4-lines; 1.75" H x 4" W

**PT** = Polyester Tag; 5-lines; 1.25" H x 2.75" W

**C** = 2 metre cable with Type C plug - widely used throughout Asia, Europe, and South America

**G** = 2 metre cable with Type G plug - Widely used in the Arabian Peninsula and United Kingdom, as well as in Ireland, Malaysia, Malta, and Singapore

**I** = 2 metre cable with Type I plug - Australia, Argentina, China, and New Zealand

**M** = 2 metre cable with Type M - Only used in South Africa


**NOTE:** The EZGasCal™ is provided with two digital sensor bases to accept gas sensors. Gas sensors are sold separately.

Options

EZGC

1+

# Global common plug types – options available with EZ GasCal™, Gas Sensor Warm-up Tray & Demo Kit



## Legend

Type A - Canada, United States, Japan, & Mexico

**Type B - Canada, United States, & Mexico**

**Type C - used throughout Asia, Europe, & South America**

Type D - India

Type E - Belgium, Czechia, France, Poland, & Slovakia

Type F - used in Europe & Russia

**Type G - used in the Arabian Peninsula & United Kingdom, as well as in Ireland, Malaysia, Malta, & Singapore**

Type H - Israel, the Gaza Strip, & the West Bank

**Type I - Australia, Argentina, China, & New Zealand**

Type J - Only used in Liechtenstein & Switzerland

Type K - Only used in Denmark & Greenland

Type L - Only used in Chile & Italy

**Type M - Only used in South Africa**

Type N - The International Electrotechnical Commission (IEC)'s choice for the standard universal plug. Mainly used in Brazil and South Africa.

Type O - Only used in Thailand